
Operating level; actuated by the operator
10
11
12
13
14
15
16
20
21
22
23
24
25
26
40
1 – On-board computer, with VDU screen, exchangeable data storage medium, control panel and radio interface
37
50
30
31
32
33
34
35
36
41
42
43
44
45
Actuator level, controlled by the FEMS

FIGURE 1